



1. Attach plastic feet to all 4 uprights - mind the orientation of the uprights.
2. Attach the side beams to the uprights at required positions, starting with the top and bottom beams to stabilise the frame. Make sure the embedded text marking is at the top of the beam for the chipboard shelf to sit flush with the beams.
3. Attach the front and back beams at the same levels as the side beams.
4. Insert deck supports to the center of each level at an angle and then twist to interlock into the the correct position.
5. Place the chipboard shelves on each level.

Tools Required

Rubber Mallet

Safety Precaution

Two competent people wearing **safety gloves**, **safety shoes** and **protective eyewear** are recommended to undertake the assembly.



scan for more info