



1. Attach plastic feet to all 4 uprights
2. Attach side beams to the uprights at desired heights and secure with a rubber mallet.
3. Attach the face beams at the same level as the side beams.
4. Attach front to back shelf support to each level, if applicable. NOTE: Only bays 762mm and 915mm deep have deck supports.
5. Place the chipboard shelves into the levels.

Z RIVET Loads and Capacities

| Shelf Pitch | Bay Load | Shelf Width | Load |
|-------------|----------|-------------|--------|
| 305mm | 2500kgs | 915mm | 300kgs |
| 457mm | 2400kgs | 1220mm | 250kgs |
| 610mm | 2300kgs | 1525mm | 200kgs |
| 762mm | 2200kgs | | |
| 915mm | 2040kgs | | |
| 1066mm | 1880kgs | | |
| 1220mm | 1800kgs | | |

*Shelf Pitch - distance between shelf levels
*Bay Load - based on 5 levels with the 1st level at the base

Tools Required

Rubber Mallet

Safety Precaution

Two competent people wearing safety gloves, safety shoes and protective eyewear are recommended to undertake the assembly.



scan for more info