

Cantilever racking instruction



COLUMN HEIGHT mm	
2000	
2500	
3000	
ARM LENGTH	LOADING CAPACITY
500mm	220kgs
600mm	185kgs
700mm	160kgs
800mm	135kgs

Ref	Description	Qty
Components per column		
1	column	1
2	single base profile 600mm	2
4	with M16 bolt, nut, 2 washers	6
2	double base profile 600mm	2
4	with M16 bolt, nut, 2 washers	8
3	front plate for base	1
5	Base floor fixing bracket	4
7	M10 x 25 nut & bolt (bracing bracket)	2
Components per bracing set		
6	Column X brace bracket	4
8	Horizontal brace 970mm	2
9	Diagonal brace 1456mm	2
10	M8 x 20 socket screw & nut	8
Components per arm		
11	Arm (500, 600, 700 & 800mm)	1
12	Arm/column locating pin	1
13	Arm plastic end plug	1
14	Arm end stop	1
15	M8 plate and M8 socket screw	1
16	End stop for base	1
17	M10 x 25 bolt and nut	1

