

**Step 1**



Insert base legs into uprights to make L shape for wall shelving or T shape for gondola shelving. To insert the base legs, locate the two upper lugs into the upright and rotate downwards to locate the lower lug, use a rubber mallet to tap the base leg into position

**Step 2**



Hold two uprights the appropriate distance apart and insert a back panel into both uprights. The back panel should locate into the inside slot of each upright. The shelving should be levelled at this point using the adjustable feet.

**Step 3**



Attach the kick panel to the base feet using the slots in a similar fashion to the back panel.

**Step 4**



Place base shelf onto base legs and then complete adding the back panels. If small back panels are used, put these on first.

**Step 5**



Once all the backpanels are fitted, you are ready to add the shelves

**Step 6**



The brackets should be positioned in the H slot of the upright and should be located in the inside slot (the back panel and bracket for the next shelving bay will use the other slot). The 3 hook brackets can be horizontal or tilted upwards or downwards as required.

**Step 7**



Repeat step 6 with the required number of brackets and then lower the correct size shelf onto the brackets.

**Step 8**



Finally add any shelf ticket strips, risers and dividers.